



## TECHNICAL SPECIFICATIONS

1 Soil elevator with double chain.

2 3bladeshorizontalrotorwithadjustablespeed. 5 Hopper700lwithbottombeltslidingonrollers.

Brush for transversal tray cleaning.

4 Electric control panel start-stop, emergency

and limit switch.

• Available in left and right version.

TECHNICAL DATA	M.U.	RE14	RE14 A	RE14 E
HOURLY PRODUCTION (max)	trays/hour	600	600	600
TRAYS DIMENSIONS (max)	mm	600x400	750x400	750x500
TRAYS HEIGHT (max)	mm	150	150	150
WEIGHT	kg	525	525	525
INSTALLED POWER	kW	2,5	2,5	2,5
HOPPER CAPACITY		700	700	700

### MACHINE DESCRIPTION

The RE14 trayfiller is recommended to fill in trays both for seeding and transplanting.


Realized to satisfy any filling request: made for expanded polystyrene, thermoformed and also for shuttle trays.


The machine is easy to use and strong, equipped with a horizontal 3 blades rotor filling system with adjustable speed so to achieve the desired soil density.

The trayfiller can be used as single machine or in line with other machines.

#### **ACCESSORIES** page 58-59







WURBINATI



# **ACCESSORIES**

### TRAYFII I FR




Electropneumatic denester with nr. 3 movements for carrier, thermoformed, injection, pot carrier and polystyrene.



### **AVAILABLE ON:**

ALL TRAYFILLER



Feeding belt for single trays or empty stacks for denester L = 3300/4300/5300/6300 mm.







Electropneumatic denester with nr. 2 movements, adjustable with a single handle; for polystyrene trays and carrier.



ALL TRAYFILLER



**Denester** for **heavy plastic trays** at injection and polystyrene **mod. DISPES**.

AVAILABLE ON:

ALL TRAYFILLER

- Advancement belt with electronically adjustable speed from 200 to 800 trays/hour.
- **Soil compactor** with rotating movement and eccentric for **adjustable density**.
- Device **for hopper emptying** with frequency driver.
- Peat hopper extension with **additional capacity of 500 l**.


**AVAILABLE ON:** RT12

• **Vibrating table** on conveyor belt.

AVAILABLE ON: ALL TRAYFILLER


## These are **some of the accessories available** for our **soil trayfiller**. Our **engineering dept.** is at your disposal **to suggest the best solutions** for your needs.





Accelerator belt 51 530 mm at the outlet for the connection to other machines.

> **AVAILABLE ON:** ALL TRAYFILLER



Fixed table at the outlet. 52

AVAILABLE ON:

RC65, RE14



Belt for the **recycling** (53) of the exceeding soil.



54



Rapid adjustment with handles of tray guide width.

**AVAILABLE ON:** RN12, RC65, RT12



55


Hopper 900 l.



Hopper 1000 I, complete (56) with bulkhead and nr. 2 turning wheels.



Adjustment device 57 for trays with legs.



Motorized exit roller (58) with nr. 4 rows.



Wheels kit for manual movement.

AVAILABLE ON: RN12, RT12 AVAILABLE ON: RC65, RE14

AVAILABLE ON: RN12, RC65, RE14

AVAILABLE ON: **ALL TRAYFILLER**  AVAILABLE ON: RC65, RE14 URBINATI WIN