

IRMO4

DOUBLE RAIL IRRIGATION BOOM





URBINATI
Nursery Technology





RECOIL SYSTEM TROLLEY MOUNTED ON BEARINGS

The use of a trolley with **wheels mounted on bearings** allows a **smoother hose sliding**, **less wearing** on components on long terms and then **less maintenance**.





NEW INSITE INSTALLATION

The **new rail frame**, designed according to its support, allows to be fitted easily: it is enough **lay the rail on the proper housing** present on both support side and connect components by **pull-down couplings**.




NEW DRIVE UNIT POSITION

The **new drive unit and hose supports configuration** reduce the gap under the shade net: **it allows to increase the ground clearance** about 130 [mm].




REVERSIBLE CONFIGURATION

Due to the particularly symmetrical structure's shape and the steel cable routing, **it is possible to install the recoil system trolley (A) before or after the trolley water boom (B)**: this solution maximizes the irrigation area reducing the headroom.



DECENTRALISED STEEL CABLE SYSTEM

The new steel cable routing permits to have a close system with a relevant advantage during installation and set up: **tensioning from a single point** and adjusting even without a water hose.



TECHNICAL DATA	M.U.	IRM04
WORKING SPEED (min-max)	m/min	2 - 16
WORKING LENGHT (max)	m	300 NEW
WORKING WIDTH (max)	m	16 NEW
DOUBLE RAIL INTERAXIS	mm	1050 NEW
WATER CONNECTION	inches	1" ¼
INSTALLED POWER (230 V)	kW	0,7

NEW FEATURE

Programmable through a **simple and intuitive interface**, it has been extended the possibility to **customize the zone setting speed and number of cycles** to each one in a unique cycle. **8 electro-valves** may be handled **independently**.



The remote control **can manage up to 240 irrigation booms** and it is available in two versions: **"easy"** used to control basic functions; **"mod-rem"**, provided by **wider display**, used to controls all the functions.



www.urbinati.com - info@urbinati.com

URBINATI s.r.l.

Via della Liberazione, 18 - 47030 San Mauro Pascoli (FC) - Italy
Tel. (+39) 0541 932018 - Fax (+39) 0541 932679

